



Reflection
 Mirrors
 Refraction
 Lenses
 Total Reflection
 Rainbow

L-1 S-1


1A



Optical disk



Light source



Box of
 accessories

Adjust source for a horizontal, approximately parallel beam. Adjust height of source to center of optical disk. Set source 3 to 4 feet from optical disk. Angle disk very slightly so that the light beam coming through the slit shows clearly on the disk. Movement of the slit assembly up or down will provide for from 1 to 5 slits.

By using the proper accessory, located at the proper place on the disk, you can show any of the items listed above.